

Avoid Common Assembly Errors Before Opening the Box

Avoid common assembly errors before opening the box. Ideal placement: After the "Building It on an Uneven Floor" section.

1. ESSENTIAL TOOLS REQUIRED



Long Spirit Level (Min 60cm)



Rubber Mallet



Pozi & Flathead Screwdrivers



Power Drill & Masonry Bits



Tape Measure



Soft Lead Pencil

2. FLOOR PREPARATION STEPS

☐ Protect the Flooring Surface

Flatten the cardboard shipping boxes and layout them across the workspace area to prevent scuffs, scratches, or damage to both your floor and the new wardrobe panels.

☐ Establish the Baseline High Point

Run your spirit level across the entire footprint area where the wardrobe will sit to identify the highest spot of an uneven floor. You will level down to this point.

3. PRE-ASSEMBLY SAFETY CHECKS

☐ Check Wall Integrity & Detection

Scan the mounting zone with a stud finder to guarantee you aren't drilling into hidden electrical wiring, metal conduits, or active plumbing lines.

☐ Two-Person Lift Confirmation

Ensure you have a secondary person available to support upright stability, specifically when tilting, lifting, or joining adjacent multi-frame segments.

4. PRECISION LEVELLING PROTOCOL

☐ Adjust Front Threaded Feet Before Anchoring

Twist and adjust the built-in leveling feet from inside the base floor panel until the frame matches absolute zero level on front-to-back and side-to-side planes.

☐ Budget for Compression Gaps

If installing over soft carpets or plush underlays, re-check levels after loading empty internal structures to guarantee the unit hasn't compressed unevenly.

5. HEAVY-DUTY WALL ANCHORING GUIDE

☐ Match Fixings to Your Specific Wall Material

Never use standard generic plastic wall plugs on hollow drywall. Utilize heavy-duty metal toggle bolts for plasterboard, or expansion anchors for solid brick/masonry.

Secure Anti-Tip Brackets Flush

Fix the top corner safety brackets directly to the structural studs or masonry wall. If uneven gaps exist behind the unit, place solid spacer blocks behind the bracket to prevent frame distortion.

Pro Installer Tip:

Attempting to align wardrobe doors on an unlevelled frame will distort the hinges and prevent square alignment. Complete all structural leveling and wall anchoring prior to unpacking any doors or drawers.

Designed by TheItalianTasker • Professional Wardrobe Assembly & Adjustments London