TheItalianTasker
Phone: 07737422842
Email: theitaliantasker@gmail.com

Free PAX / GRIMO Assembly Checklist

A simple one-page checklist covering parts, tools, frame alignment, doors, wall anchoring and final safety checks. (Placement: Immediately after the Final Inspection section.)

Ready to build your PAX / GRIMO wardrobe? Keep your workspace, tools, and safety checks organised from start to finish.

DOWNLOAD THE FREE ASSEMBLY CHECKLIST

1. PARTS & ESSENTIAL TOOLS SETUP

- [ ] **Parts & Panels Inventoried:** Verify all PAX carcass panels, GRIMO door leaves, and KOMPLEMENT components against delivery notes before unboxing.
- [ ] **Hardware Grouped & Tools Audited:** Sort cam-locks, dowels, and hinge plates into sorting trays; ensure a 60cm spirit level, rubber mallet, screwdrivers, and tape measure are on hand [cite: 7, 18].
- [ ] **Floor Shielding & Height Clearances Verified:** Lay flat cardboard over the work zone [cite: 7, 11, 26]; if ceiling clearance is under 1cm, assemble the frame vertically from the ground up [cite: 1, 2, 10, 26].

2. FRAME ASSEMBLY & CARCASS ALIGNMENT

- [ ] **Carcass Fixings Fully Torqued:** Tighten all structural bolts, cams, and dowels across base, sides, and top panels to eliminate joint play and frame flex [cite: 70].
- [ ] **Diagonal Squareness Confirmed:** Measure diagonally from corner to corner before securing backboards to prevent chassis twist and misaligned door reveals [cite: 14, 16, 70].
- [ ] **Base Leveled for Uneven Floors:** Check floor baseline with a spirit level and adjust front feet shims so frame weight rests safely backward against the wall [cite: 18, 24, 70].

3. GRIMO DOORS & INTERNAL STORAGE

- [ ] **Hinged Doors & Soft-Close Adjusted:** Mount GRIMO doors, dial in 3-way hinge screws for consistent margins, and verify soft-close dampers engage smoothly [cite: 70].
- [ ] **KOMPLEMENT Interiors Glide Freely:** Check that drawers, pull-out shoe racks, and wire baskets open without rubbing side walls or catching door hinges [cite: 70].

4. WALL ANCHORING & FINAL SAFETY CHECKS

- [ ] **Wall Substrate Scanned & Anchored:** Sweep partitions with an electronic multi-detector for cables/pipes, then fasten anti-tip brackets into solid timber studs or masonry [cite: 2, 8, 10, 14, 70].
- [ ] **Zero Unexplained Components Remaining:** Audit the workspace to confirm all shelf pins, bracket caps, and fasteners are installed with no leftover spare parts [cite: 70].

🚨 **Mandatory Anti-Tip Safety Notice:**
Tall PAX wardrobes must never be loaded until wall anchoring is 100% complete and tested [cite: 70]. For professional wardrobe assembly across London with guaranteed fixed pricing, contact our installation specialists [cite: 20, 24].